

STICK BOOT PATTERN

3/4" flange for
attaching all
around

Fold over 180° • Glue, install eyelets for shoelace

Fold in and
sew allowing
slot for Tie
Wrap around
stick

Start by drawing circle
8.5" radius

Construct sections by
measuring front
section at 4.5" wide
then sides at 7" long
and add 3/4" flange to
outside.

Material is thin leather
or naugahyde

Design by Mike Fothergill

Left half of symmetrical
pattern shown

