



4. Use "L" angles between 6V11-5 extrusions to reinforce plexiglas. Do not rivet to plexiglas. Use small screws or bolts. Drill plexiglas holes oversize.